

ATTENTION!

Never use caustic nor harsh cleaning agents, which may scratch the surface of the thermal jug.

- Prior to first use and after each subsequent use clean the thermal jug, the lid and, if needed, the pump's pipe thoroughly, using warm water and mild cleaning agent.
- To end with, rinse the thermal jug, lid and, if needed, the pump's pipe a few times with fresh water.
- To remove stubborn residues from the thermal jug, use generally available cleaning agents. Observe the instructions of the cleaning agent's manufacturer.
- Wipe the exterior of the thermal jug with a soft, damp cloth.
- After cleaning, leave the thermal jug open to dry completely.

Bartscher GmbH
Franz-Kleine-Str. 28
33154 Salzkotten
Germany

phone: +49 5258 971-0
fax: +49 5258 971-120
Service-Hotline: +49 5258 971-197
www.bartscher.com