



Pos.	Artikelbeschreibung	Description of item	Artikel Nr./Item No.
1	Gehäuse	Housing	E0B130B
2	Bedienblende	Front panel	E0B106TBB
3	Andeckung unten	Lower cover	E0B136B
4	Rahmen	Frame	E0B133B
5	Fettauffangschale	Grease drip pan	E0B131B
6	Grillplatte unten	Lower grill plate	E0B132EB
7	Grillplatte oben	Upper grill plate	E0B126EB
8	Abdeckung oben	Upper cover	E0B123B
9	Heizkörper	Heating element	E0B111B
10	Heizkörper	Heating element	E0B108B
11	Halteplatte	Support plate	E0B134B
12	Halteplatte	Support plate	E0B125B
13	Griff, Kunststoff	Handle, plastic	E0KLB121
14	Abdeckung	Cover	E0B128B
15	Verschraubung	Screw connection	E0B122
17	Feder	Spring	E0KLB127
18	Zugentlastung	Strain relief	E0KLB138
19	Anschlusskabel m. Stecker	Power cord w. plug	A039896
20	Adapter, verstellbar	Adapter, adjustable	E0B129
21	Timer, Platine	Timer board	E0KLB109
22	Thermostat 50 - 310° C	Thermostat 50 - 310° C	E0KLB118
23	Kontrolllampe, grün	Green indicator light	E0KLB119
24	Fuß	Base	E0KLB117
25	Knebel f. Thermostat	Knob f. thermostat	E0KLB120
26	Schalter, Nockenschalter	Switch, change over switch	E0KLB102
27	Kontrolllampe, rot	Red indicator light	E0KLB101
28	Knebel Ein - Aus	Knob on - off	E0KLB103
29	Feder	Spring	E0B104B
30	Knebel	Knob	E0B100
31+32	Bügel komplett, Metall	Complete clamp, metal	E0B107B
16 A+B	Isolierung, Set	Insulation set	E0B115B
o.Abb/n.pic	Schaber	Scraper	E0B139



Kontaktgrill 2500 1R
Artikel-Nr.: A150691

Ersatzteilliste
04.05.2017